

INSTALLATION OF A BIOTIZER® DISPENSER



TOOLS AND HARDWARE NEEDED FOR AN EASY INSTALLATION

- ▶ Cordless, variable speed drill motor
- ▶ Drill bit depending on anchors used
- ▶ Phillips type screwdriver
- ▶ Level
- ▶ Four (4) Wall anchors for #6 or #8 screw size
- ▶ For rough or irregular walls, a 6" x 12" board or plywood may be necessary

LOCATING THE MOUNTING SITE

- ▶ The first thing to decide is the best location for the dispenser (usually near the most used sink) where a drain line can be accessed, but preferably well downstream from where the dishwasher empties into the drain line as very hot water from the dishwasher will reduce the effectiveness of the bioremediation activity

MOUNTING THE DISPENSER – STEP 1

- ▶ Tape the template (provided with the dispenser) to the wall at the desired location, making sure the paper is level

MOUNTING THE DISPENSER – STEP 2

- ▶ Using a marker (pencil or other), make a small hole through the template at the ✕ (4 places) and mark the wall.

MOUNTING THE DISPENSER – STEP 3

- ▶ Drill a hole at each of the four marked locations of the correct size for the anchors being used, then insert the anchors
- ▶ Note: If self drilling anchors are used (usually in walls made of a composite such as drywall) – the above step is omitted

MOUNTING THE DISPENSER – STEP 4

- ▶ Using one of the $\frac{5}{8}$ " to $\frac{3}{4}$ " long screws of the size (#6 or #8) needed by the anchors, insert through the top-most anchor hole in the dispenser and into the wall anchor. Tighten snugly, but don't over-tighten to avoid cracking the dispenser housing.
- ▶ Repeat this procedure, first through the bottom-most anchor hole followed by the two holes between the upper and lower mounting holes

INSTALLATION OF FEEDING TUBE

- ▶ There are two different methods of installing the feeding tube.
- ▶ One method is routing the tube through the p-trap and into the drain line.
- ▶ The second is drilling a hole and installing a fitting in the drain line before it goes underground.
- ▶ A .pdf file showing each method is available in Printable .pdf files under the About Us TAB.