

# Steps for performing monthly service on the biotizer<sup>®</sup> Dispenser

The time to service the  
biotizer<sup>®</sup> dispenser is less  
than one minute

# PREPARATIONS (do this 1 or 2 days before scheduled service)

- Unscrew the filler cap of a new bag being careful to not spill the powdered product inside the bag
- Place bag in sink and fill with 3-liters of tap water
- Replace the cap. If it leaks, the cap is cross threaded. Remove and reattach – being careful to not cross-thread



# UNLOCK THE COVER

- TURN THE KEY  
COUNTER-CLOCKWISE  
TO UNLOCK THE  
COVER



# TURN POWER OFF

- PUSH THE BOTTOM

HALF OF THE  
ROCKER SWITCH  
TO TURN THE  
POWER OFF



# DISCONNECT FEEDER TUBE

- GENTLY PULL THE FEEDER TUBE OFF THE PUMP INLET



# REMOVE AND DISPOSE OF THE EMPTY BAG

- Remove the empty bag by unhooking it from inside the dispenser, disposing of the empty bag responsibly



# PLACE NEW BAG IN DISPENSER

- While holding the bag in one hand by the filler, squeeze bottom of bag with the other hand so it can easily be placed into the dispenser
- Secure by engaging the left loop above the filler cap onto the bag hook inside the dispenser



# REMOVE TAPE AND ATTACH FEEDER TUBE TO PUMP INLET

- While keeping the end of the tube above the top of the bag to prevent spillage, remove tape from the tube
- Push end of tube onto pump inlet, making sure it is fully engaged.



# TURN POWER ON

- PRESS THE TOP HALF OF THE ROCKER SWITCH TO TURN THE POWER ON



# VERIFY PROPER OPERATION

- The indicator light will flash green 3 times after the power is turned on, indicating proper operation
- Observe to be sure dosing material is being pumped
- If the indicator light flashes red instead of green, the batteries need to be replaced



# LOCK THE COVER

- TURN THE  
KEY CLOCKWISE  
TO LOCK COVER

